



Grandstream DP715/DP710 VoIP DECT Phone Quick User Guide

Basic Phone Operation

For detailed information please consult the DP715/710 User Manual available at:
www.grandstream.com

©2014 Grandstream Networks, Inc. All rights reserved.
Reproduction or transmittal of the entire or any part, in any form or by any means, electronic or print, for any purpose without the express written permission of Grandstream Networks, Inc. is not permitted. Information in this document is subject to change without notice.

Basic Phone Features

USING THE HANDSET

- 1) Hold the Power Button  to turn handset ON/OFF.
- 2) Use the Speaker Button  to switch between the handset and speaker while you are in the call.

MAKING A CALL

- 1) Press  to start a call.
- 2) After you hear the dial tone, input the remote party's number.
- 3) After finishing dialing, wait for 4 seconds (Default "No Key Entry Timeout"); or press # to dial the number directly ("Use # as dial key" must be configured in web configuration).

ANSWERING CALLS

There are two ways to answer an incoming call:

- 1) Press  to pick up the call.
- 2) Pick up the handset from the base or charger unit (Only if "Auto Talk" option on handset menu is activated).

ENDING A CALL

To end a call, press  or place the handset in the base or the charger unit.

CALL HOLD/RESUME

Pressing the "Recall" button  during a call will place it on hold. Pressing the "Recall" button  again will resume conversation.

CALL TRANSFER

Assuming that you are in a call and wish to transfer the call to another party.

BLIND TRANSFER:

- 1) Press  on the handset to hold the current call.
- 2) After you hear the dial tone, dial *87 plus transfer target number, and then press # (or wait for 4 seconds).
- 3) Call will be disconnected after transfer is finished.

ATTENDED TRANSFER

- 1) Press  on the handset to hold the current call.
- 2) After you hear the dial tone, dial the transfer target number, and then press # (or wait for 4 seconds).
- 3) After your transfer target answers, You can simply hang up your call to finish the transfer.
- 4) If your target does not answer the call, you can press  to resume the original call.

3-WAY CONFERENCE

INITIATE A CONFERENCE CALL

Assuming that you are in a call and want to bring a third party into conference:

- 1) Press  on the handset to hold the current call.
- 2) After you hear the dial tone, input the third party's number and dial out.
- 3) If the third party answers, then press  to bring both parties into the conference.
- 4) If the third party does not answer the call, you can press  to resume the original call.
- 5) If  is pressed during conference, the third party will be dropped out.

END THE CONFERENCE

If you hang up, the conference will be terminated for all three parties. If the "Transfer on Conference Hangup" feature is enabled on phone, then after you hang up, the rest parties will still remain on the line for further conversation.

VOLUME ADJUSTMENTS

During a call, you can use the  arrow keys to adjust the call volume. In order to adjust the ring volume, please use the handset soft key  on idle screen to get into handset menu, and follow the instruction by DP715/710 User Manual.

MUTE

Press  soft key to switch off the microphone during a call. You can now talk freely without the other party hearing you. Press again to switch on the microphone.

PHONEBOOK

Press the phonebook soft-key  to access the phone-book.

CALL HISTORY

OUTGOING CALL HISTORY

On idle screen, press  to retrieve the most recent outgoing call entries. If you want to call again, highlight the entry by  /  and press  to dial out.

INCOMING CALL HISTORY

On idle screen, press  to retrieve the most recent incoming call entry. If you want to make a call back, you can toggle between the entries by  /  and press  to dial out.